

Attaching of the Clip-On Clear

Retrofit kit with full protection for our metal visors G16 and F39



- 1) First, attach the two caps on the top and bottom of the metal visor using the screws provided.
- 2) The two holes in the middle of the visor determine the correct position.
- 3) You can hold the caps firmly with a pair of needle nose pliers and tighten them hand-tight.



- 4) After that you can clip on the Clip-On Clear over the two caps. Now you can bend the Clip-On Clear to the sides of the metal visor.
- 5) The holes on the sides of the Clip-On Clear show which grid hole the screws have to be screwed into. Please turn the screws all the way through the grid first. Then you can assemble the caps with the needle nose pliers and tighten them hand-tight. After that you can also clip on the sides of the Clip-On Clear over the caps on the sides.



Fully equipped metal visor with the Clip-On Clear.

1 set includes:
4 protective slides
5 caps, including screws

Perfect for anyone who already has a metal visor!